

# Boston University Classrooms

## QUICK-START OPERATION INSTRUCTIONS: CRESTRON TSW-760 CONTROL PANEL W/ COMPUTER

### TURN ON THE MEDIA SYSTEM & SELECT SOURCE:

- 1
  - Touch the screen to activate.
  - Press the button along the bottom that states “**Touch here to start your presentation**”. The projector will power up and turn on once your source is selected (below). Please lower the manual or electric projection screen.
  - Choose **COMPUTER SOURCE** or **DVD PLAYER** along the bottom of the control panel
- 2
  - **COMPUTERS:** Select your source. Select DESKTOP to use the built-in computer. To connect wirelessly, select the Wireless Presentation option and follow the instructions on the projection screen. Connect via the Wall or Rack Interface to use your own laptop.
  - **DVD PLAYER:** Insert your standard or Blu-ray DVD into the Blu-ray Player in the A/V cabinet
  - *Note: VGA and HDMI cables are provided in the rack drawer in the A/V cabinet. There is also a backup VGA and HDMI input available in the rack.*




### ADJUST VOLUME:

- 3
    - Touch VOLUME button, then use the “Volume Up/Down” buttons to adjust the level.
    - Be sure that “Volume Mute” is not highlighted
- NOTE: This controls volume for both Computer Audio and DVD sources. Please remember to check the volume on your laptop.*



### TURN OFF THE SYSTEM AFTER USE:

- 4
    - Touch the POWER button on the bottom right. 
    - When asked, confirm that you want to turn the system off.
    - Please return the projection screen to the raised position
- NOTE: The installed laser projector takes a few seconds to cool down, after which system restart can occur*

### QUESTIONS OR EQUIPMENT PROBLEMS?:

- 5
  - **For immediate assistance, please call LETS at (617) 353-3227**
  - Send an email to [classrooms@bu.edu](mailto:classrooms@bu.edu) to report equipment issues

